

# PFAFF



## **Applied Shower Wrap**

Created especially for Pfaff

Slip into our appliqued terry wrap after a relaxing shower and you'll feel like you're being pampered at a luxurious spa! Brush and mirror appliques and custom bias binding trim add a touch of whimsy to this adorable yet practical project.

### **SUPPLIES YOU'LL NEED:**

McCall's pattern #2475

Terrycloth yardage according to pattern

3/4-yard of fabric for bias binding

Scrap of metallic-like fabric for mirror and brush

1/4-yard of Velcro™ brand Half and Half hook and loop tape

Bias tape maker

Bias binder

Applique foot

Narrow Edge foot

Fusible web

Tear-away stabilizer

Robison-Anton rayon thread (coordinating colors)

### **FABRIC CUTTING INSTRUCTIONS:**

1. Cut the wrap according to the pattern directions.
2. Cut a 1"-wide bias strip equal to the edge of the wrap excluding the bottom edge.

# PFAFF

3. Cut a 1 1/2"-wide bias strip equal to the width of the front and back pattern pieces plus 3 yards (approximately 108").
4. Trace the applique pattern onto pattern tracing material making a pattern for each different section. Press the fusible web to the back of the scraps of bias binding fabric and the metallic fabric. Cut out each piece.

## **LET'S GET STARTED:**

1. Run the 1 1/2" bias strip through the bias tape maker and press under edges. Fold the bias strip in half lengthwise with wrong sides together and press. Cut two 18" long bias strips for the shoulder straps.
2. Stitch the darts and side seams following the pattern directions.
3. Attach hook and loop tape as indicated on the pattern.
4. Turn up a 1/2" hem along the bottom edge of the wrap and stitch in place with an overcast stitch such as no.24 or 29 on the Pfaff *creative* 2140. Adjust the stitch width if necessary so the raw edge of the terry cloth is enclosed in the stitch.
5. Attach the bias binder to your sewing machine. Using the 1"-wide bias strip, bind the edges of the wrap, turning under 1/2" at each end of the bias strip to enclose the edges.
6. Lay the terry wrap on a flat surface. Mark a horizontal line just under the bust line beginning at the right front edge and ending at the edge of the hook and loop tape on the left front.
7. Pin the long bias strip along the marked line, leaving an 18" length at each end for ties. Using the Narrow Edge foot, stitch along each edge of the bias strip.
8. Pin the shoulder straps in place and adjust as needed. Using a bartack, stitch no.60 on the Pfaff *creative* 2140, secure each strap in place.
9. Fuse the applique pieces to the front corner of the wrap layering the fabric pieces as necessary. Stabilize the terrycloth with tear-away stabilizer. Using your applique foot, stitch around the edges with a 2.5mm satin stitch.
10. Remove the stabilizer and carefully press the applique from the wrong side.