

Zipper Foot

Pfaff GrandQuilter
#416 04 82 01

The zipper foot moves from left to right so the needle can stitch very close to the zipper.

Machine Settings:

Thread tension: 4-5

Stitch length: 2-5

Foot pressure: 3-5

1. Attach the Adjustable Zipper foot to the presser bar.
2. Slide the zipper foot to the left or right to adjust the position and tighten the thumb screw (A) on the zipper foot.
3. To sew close to the right zipper teeth, set the needle to the left side of the zipper foot.
4. Lower the zipper foot at the end of the zipper and stitch close to the zipper.
5. to sew close to the left zipper teeth set the needle to the right side of the zipper foot.

