

# The Pfaff **cover** | **style**

for a perfect result!

## All features at a glance!



- **2 needles, 5 threads and 18 stitch programs**
- **Perfect sewing, trimming, and finishing in one step!**
- **Perfectly even seams!** The differential feed prevents seams from stretching or puckering.
- **Sew rolled hems easily** without changing the presser foot or needle plate.
- **All important settings are within easy reach** on the outside of the machine.
- **The presser foot lift is conveniently placed**, leaving your hand free to hold the fabric.
- **Easy threading!** All threading paths are color-coded.
- **The thread chain cutter** is conveniently placed!
- A universal standard **presser foot** is included for sewing all stitches.
- **High presser foot lift** to accommodate several layers and heavy fabrics.
- **Each fabric is optimally fed.** Presser foot pressure can be individually set.
- **Perfectly stable**, thanks to the rubber feet.
- All included! **Lots of accessories in the practical accessory box.**
- Change the presser foot? Easy on and easy off, thanks to "**snap-on**" system.
- **Detailed instructions in the manual** including many illustrations.
- The **dust cover** protects the overlock/serger when not in use.
- **The decorative 2-thread flatlock stitch** is extremely flat and elastic. Perfect for decorative effects.
- Quick needle threading! With **needle threader**.
- Practical! Use the **needle inserter** to change needles quickly and easily.
- In addition, **integrated threading levers** to thread loopers easily.
- **Safety first!** When the front cover and/or swivel plate is open, it is impossible to use the overlock/serger.
- **The 5 mm cover stitch** for sewing and hemming in one step or for creating fantastic, decorative effects.
- **Generous work area** with the sewing table in place!
- For large **thread spools** and to have more room when sewing, simply slide the spool holder to the back.
- Durable stitches with the **double chain stitch!**
- Professional stitch: **the 5-thread safety stitch!**
- Ease of use, simply change needle positions, switch to the sewing table, disengage the knife and you are ready to sew a coverstitch.